



1. Install the SunPipe as set out in the installation instructions, but do not fit the ceiling diffuser. If the ceiling diffuser is already fitted, gently prise off the diffuser trim, twist the little turn buttons on the fixing ring and remove the diffuser.
2. Mark the position of the hole to be drilled (300mm (12") up from the base of the bell end) on the outside of the SunPipe and drill a 10mm diameter hole through the SunPipe.
3. Remove any burrs from the inside and outside of the SunPipe taking care not to scratch the inside of the SunPipe.
4. Pivot lamp holder through 45° and remove the locking nut. From the inside of the SunPipe pass the wires and threaded end of the holder through the hole previously drilled in the SunPipe.
5. Place the shake-proof washer over the threaded end of the lamp holder, thread the nut onto the lamp holder and finger tighten.
6. Angle lamp holder to point down towards the ceiling as shown and tighten locking nut. Push fit the lamp into the holder.
7. Fit the ceiling diffuser as detailed in the SunPipe installation instructions.
8. Using the connecting block connect the two wires from the lamp holder and the two wires from the transformer (not the brown and blue wires). The transformer can now be screwed to a rafter, if required.

WIRING TO THE MAINS MUST BE CARRIED OUT BY A QUALIFIED ELECTRICIAN