



Technical data

Substance	
Backing	elastic PE film
Adhesive	Acrylate contact adhesive
Release film	siliconized paper

Attribute	Regulation	Value
Colour		white / blue
Exposure time		6 months
Application temperature		above -10 °C / 14 °F
Temperature resistance		permanent -40 °C/-40 °F to +90 °C/194 °F
Storage		cool and dry

Area of application

COMPEGO is used to bond overlaps between vapour check and airtightness membrane securely, air tightly and permanently as well as for indoor and exterior joints between such membranes. Also suitable for bonding butt joints between woodbased panels.

Forms of delivery

Art. no.	GTIN	Length	Width	Weight	PU	Container
15357	4026639153579	25 m	6 cm	7 kg	1	42
15385	4026639153852	25 m	10 cm	11.7 kg	1	42
15386	4026639153869	25 m	15 cm	17.5 kg	1	42

Advantages

- ✓ 6 months of outdoor exposure
- ✓ With elastic backing film, can be torn off by hand
- ✓ For airtight bonds according to DIN 4108-7, SIA 180 and OENORM B 8110-2
- ✓ Waterproof adhesive
- ✓ Lowest VOC rating in hazardous substance test

Substrates

Before sticking, subsurfaces should be brushed off, wiped clean with a cloth or cleaned using compressed air.

Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on materials to be bonded. Subsurfaces must be sufficiently dry and have sufficient load-bearing capacity.

Permanent adhesion is achieved on all vapour retarder and airtight membranes (e.g. those made of PE, PA, PP and aluminium) as well as other underlay/sarking and wall lining membranes (e.g. those made of PP and PET).

Adhesion and joints can be carried out on planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.), hard wood-based panels (chipboard, OSB and plywood panels, MDF board and softwood fibre sub-roof panels).

Wood fibre sub-roof panels and smooth mineral subsurfaces require pre-treatment with TESCON PRIMER RP before bonding. Concrete or plaster subsurfaces must not be sandy or crumbling.

The best results in terms of structural stability are achieved on high-quality subsurfaces.

It is your responsibility to check the suitability of the subsurface; adhesion tests are recommended in certain cases.

Pretreatment with TESCON PRIMER RP is recommended in the case of subsurfaces with insufficient load-bearing capacity.

General conditions

The bonds should not be subjected to tensile strain.

After sealing the vapour retarding membranes, the weight of the insulating material must be borne by lathing.

Adhesion should be supported by battens if necessary.

Press firmly to secure the adhesive tapes, taking care to ensure that there is sufficient resistance pressure behind them.

Windproof, airtight or rainproof seals can only be achieved on vapour retarding membranes, roof lining membranes or façade membranes that have been laid without folds or creases.

Ventilate continuously and systematically to prevent build-up of excessive humidity; use a dryer if necessary.

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Distributed by :



sales: 01793 847 444

email: info@ecomerchant.co.uk

web: www.ecomerchant.co.uk